


User Manual



ECU-4784 Series

**IEC-61850 Power Substation
2U Rackmount Server with
6th & 9th Gen Intel® Processor**

ADVANTECH

Enabling an Intelligent Planet

Copyright

The documentation and the software included with this product are copyrighted 2025 by Advantech Co., Ltd. All rights are reserved. Advantech Co., Ltd. reserves the right to make improvements in the products described in this manual at any time without notice. No part of this manual may be reproduced, copied, translated, or transmitted in any form or by any means without the prior written permission of Advantech Co., Ltd. The information provided in this manual is intended to be accurate and reliable. However, Advantech Co., Ltd. assumes no responsibility for its use, nor for any infringements of the rights of third parties that may result from its use.

Acknowledgments

Intel, Pentium, Celeron, and Atom are trademarks of Intel Corporation.

Microsoft Windows and MS-DOS are registered trademarks of Microsoft Corp.

All other product names or trademarks are properties of their respective owners.

Support

For more information on this and other Advantech products, please visit our websites at: <http://www.advantech.com>

For technical support and service, please visit our support website at:
<http://www.advantech.com/support/>

This manual is applicable to the following models:

ECU-4784-C3xxxx

ECU-4784-E3xxxx

ECU-4784-E4xxxx

ECU-4784-E5xxxx

ECU-4784-G5xxxx

Product Warranty (2 Years)

Advantech warrants the original purchaser that each of its products will be free from defects in materials and workmanship for two years from the date of purchase.

This warranty does not apply to any products that have been repaired or altered by persons other than repair personnel authorized by Advantech, or products that have been subject to misuse, abuse, accident, or improper installation. Advantech assumes no liability under the terms of this warranty as a consequence of such events.

Because of Advantech's high quality-control standards and rigorous testing, most customers never need to use our repair service. If an Advantech product is defective, it will be repaired or replaced free of charge during the warranty period. For out-of-warranty repairs, customers will be billed according to the cost of replacement materials, service time, and freight. Please consult your dealer for more details.

If you believe your product to be defective, follow the steps outlined below.

1. Collect all the information about the problem encountered. (For example, CPU speed, Advantech products used, other hardware and software used, etc.) Note anything abnormal and list any onscreen messages displayed when the problem occurs.
2. Call your dealer and describe the problem. Please have your manual, product, and any helpful information readily available.
3. If your product is diagnosed as defective, obtain a return merchandise authorization (RMA) number from your dealer. This allows us to process your return more quickly.
4. Carefully pack the defective product, a completed Repair and Replacement Order Card, and a proof of purchase date (such as a photocopy of your sales receipt) into a shippable container. Products returned without a proof of purchase date are not eligible for warranty service.
5. Write the RMA number clearly on the outside of the package and ship the package prepaid to your dealer.

Declaration of Conformity

CE

This product has passed the CE test for environmental specifications when shielded cables are used for external wiring. We recommend the use of shielded cables. This type of cable is available from Advantech. Please contact your local supplier for ordering information.

Test conditions for passing also include the equipment being operated within an industrial enclosure. In order to protect the product from damage caused by electrostatic discharge (ESD) and EMI leakage, we strongly recommend the use of CE-compliant industrial enclosure products.

FCC Class A

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference. In this event, users are required to correct the interference at their own expense.

Technical Support and Assistance

1. Visit the Advantech website at www.advantech.com/support to obtain the latest product information.
2. Contact your distributor, sales representative, or Advantech's customer service center for technical support if you need additional assistance. Please have the following information ready before calling:
 - Product name and serial number
 - Description of your peripheral attachments
 - Description of your software (operating system, version, application software, etc.)
 - A complete description of the problem
 - The exact wording of any error messages

Packing List

Before system installation, check that the items listed below are included and in good condition. If any item does not accord with the list, contact your dealer immediately.

- 1 x ECU-4784 Product
- 4 x 10-pin green screw terminals
- 16 x jumper caps
- 2 x M3 black screws for USB clamp
- 1 x clamp for USB dongle
- 2 x HDD hold BRK (with black HDD Mylar)
- 8 x M3*5L ST Ni Screw
- 4 x Cu NYLOK
- 3 x Label POWER2
- 1x ROHS LIST
- 1 x Warranty Card

Safety Precautions - Static Electricity

Follow these simple precautions to protect yourself from harm and the products from damage.

- To avoid electrical shock, always disconnect the power from the PC chassis before manual handling. Do not touch any components on the CPU card or other cards while the PC is powered on.
- Disconnect the power before making any configuration changes. A sudden rush of power after connecting a jumper or installing a card may damage sensitive electronic components.

Safety Instructions

1. Read these safety instructions carefully.
2. Retain this user manual for future reference.
3. Disconnect the equipment from all power outlets before cleaning. Use only a damp cloth for cleaning. Do not use liquid or spray detergents.
4. For pluggable equipment, the power outlet socket must be located near the equipment and easily accessible.
5. Protect the equipment from humidity.
6. Place the equipment on a reliable surface during installation. Dropping or letting the equipment fall may cause damage.
7. The openings on the enclosure are for air convection. Protect the equipment from overheating. Do not cover the openings.
8. Ensure that the voltage of the power source is correct before connecting the equipment to a power outlet.
9. Position the power cord away from high-traffic areas. Do not place anything over the power cord.
10. All cautions and warnings on the equipment should be noted.
11. If the equipment is not used for a long time, disconnect it from the power source to avoid damage from transient overvoltage.
12. Never pour liquid into an opening. This may cause fire or electrical shock.
13. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.
14. If any of the following occurs, have the equipment checked by service personnel:
 - The power cord or plug is damaged.
 - Liquid has penetrated the equipment.
 - The equipment has been exposed to moisture.
 - The equipment is malfunctioning, or does not operate according to the user manual.
 - The equipment has been dropped and damaged.
 - The equipment shows obvious signs of breakage.
15. Do not leave the equipment in an environment with a storage temperature of below -25°C (-13°F) or above 70°C (158°F) as this may damage the components. The equipment should be kept in a controlled environment.
16. CAUTION: Batteries are at risk of exploding if incorrectly replaced. Replace only with the same or equivalent type as recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.
17. Due to the sensitive nature of the equipment it must be stored in a restricted access location, only accessible by qualified engineers.
18. When installing this equipment, ensure that the Earth cable is securely attached using a 3.5 mm screw.
19. The equipment does not include a power cord and plug.
20. In accordance with IEC 704-1:1982 specifications, the sound pressure level at the operator's position should not exceed 70 dB (A).
21. This device is an open type, and it needs to maintain a surrounding space of a minimum of 25 mm.

DISCLAIMER: These instructions are provided according to IEC 704-1 standards. Advantech disclaims all responsibility for the accuracy of any statements contained herein.

Consignes de sécurité

1. Lisez attentivement ces consignes de sécurité.
2. Conservez ce manuel d'utilisation pour référence future.
3. Débranchez l'équipement de toutes les prises de courant avant de le nettoyer. Utilisez uniquement un chiffon humide pour le nettoyage. N'utilisez pas de détergents liquides ou en spray.
4. Pour les équipements enfichables, la prise de courant doit être située à proximité de l'équipement et facilement accessible.
5. Protégez l'équipement de l'humidité.
6. Placez l'équipement sur une surface fiable lors de l'installation. Faire tomber ou laisser tomber l'équipement peut provoquer des dommages.
7. Les ouvertures sur le boîtier sont destinées à la convection de l'air. Protégez l'équipement de la surchauffe. Ne couvrez pas les ouvertures.
8. Assurez-vous que la tension de la source d'alimentation est correcte avant de connecter l'équipement à une prise de courant.
9. Éloignez le cordon d'alimentation des zones à fort trafic. Ne placez rien sur le cordon d'alimentation.
10. Toutes les mises en garde et avertissements figurant sur l'équipement doivent être notés.
11. Si l'équipement n'est pas utilisé pendant une longue période, débranchez-le de la source d'alimentation pour éviter tout dommage dû à une surtension transitoire.
12. Ne versez jamais de liquide dans une ouverture. Cela pourrait provoquer un incendie ou un choc électrique.
13. N'ouvrez jamais l'équipement. Pour des raisons de sécurité, l'équipement ne doit être ouvert que par un personnel de service qualifié.
14. Si l'un des événements suivants se produit, faites vérifier l'équipement par le personnel de service:
 - Le cordon d'alimentation ou la fiche est endommagé.
 - Du liquide a pénétré dans l'équipement.
 - L'équipement a été exposé à l'humidité.
 - L'équipement fonctionne mal ou ne fonctionne pas conformément au manuel d'utilisation.
 - L'équipement est tombé et a été endommagé.
 - L'équipement présente des signes évidents de casse.
15. Ne laissez pas l'équipement dans un environnement où la température de stockage est en dessous de -25°C (-13°F) ou au-dessus de 70°C (158°F), car cela pourrait endommager les composants. L'équipement doit être conservé dans un environnement contrôlé.
16. **ATTENTION:** Les piles risquent d'exploser si elles sont mal remplacées. Remplacez uniquement par un type identique ou équivalent recommandé par le fabricant. Jetez les piles usagées conformément aux instructions du fabricant.
17. En raison de la nature sensible de l'équipement, il doit être stocké dans un endroit à accès restreint, accessible uniquement par des ingénieurs qualifiés.
18. Lors de l'installation de cet équipement, assurez-vous que le câble de terre est solidement fixé à l'aide d'une vis de 3,5 mm.
19. L'équipement ne comprend pas de cordon d'alimentation ni de fiche.
20. Conformément aux spécifications CEI 704-1:1982, le niveau de pression acoustique au poste de l'opérateur ne dépasse pas 70 dB (A). **AVIS DE NON-RESPONSABILITÉ:** Ces instructions sont fournies conformément aux normes

CEI 704-1. Advantech décline toute responsabilité quant à l'exactitude des déclarations contenues dans le présent document.

21. Cet appareil est de type ouvert et doit maintenir une distance environnante min. 25 mm.

Contents

Chapter 1 Overview.....1

1.1	Introduction	2
1.2	Hardware Specifications	4
1.3	Environment.....	5
1.4	Functional Block Diagram	5
	Figure 1.1 ECU-4784 with 6th & 9th Gen Intel® Processor Functional Block	5
1.5	Safety Precautions	6
1.6	Chassis Dimensions.....	7
	Figure 1.2 ECU-4784 Series Chassis Dimensions	7
	Figure 1.3 ECU-4784 Series Exploded Diagram	8

Chapter 2 Hardware Function 9

2.1	Overview	10
2.1.1	ECU-4784 LED and Interface Position	10
	Figure 2.1 ECU-4784 Front Panel	10
	Figure 2.2 ECU-4784 Rear Panel	10
2.2	LED Indicators.....	10
2.2.1	ECU-4784 LED Indicators.....	10
	Table 2.1: Definition of System Status Indicators	11
	Table 2.2: Definition of LAN Status Indicators	11
	Table 2.3: Definition of Serial COM Status Indicators	12
	Table 2.4: Programmable LED Status Indicators	12
2.3	Power Input.....	13
	Table 2.5: Power Input	13
	Figure 2.3 Power1 Input Location	13
	Table 2.6: AC/DC Power Input PIN Definitions	14
	Table 2.7: Jumper Settings for ATX/AT Power Mode.....	14
	Figure 2.4 AT X/AT Power Mode Select Location (CN67).....	15
2.4	RS-232 Interface (COM1, COM2).....	15
2.5	RS-232/422/485 Interface (COM3~COM10).....	16
	Table 2.8: Jumper Settings for RS-232/RS-422/RS-485 (For COM(3~10)).....	16
	Table 2.9: Mapping Table of Jumpers for COM (3~10) Ports....	16
	Table 2.10: Switch Settings for RS-422 Primary/Secondary Selection.....	16
	Figure 2.5 COM3~10 Port-Related Jumper Locations (CN16-CN23)	17
	Figure 2.6 COM3~10 Port-Related Jumper Locations (SW2) ...	17
2.5.1	UART Chips	18
2.5.2	RS-422/485 Detection.....	18
2.5.3	Automatic Data Flow Control Function for RS-485	18
2.5.4	Terminal Resistor for RS-485	18
	Table 2.11: Jumper Settings for Terminal Resistors (for COM (3~10)).....	18
	Table 2.12: Mapping Table of Jumpers for COM (3~10) Ports....	19
	Figure 2.7 COM3~10 Port-Related Jumper Locations (CN27-CN34)	19
2.6	Relay Output For Events.....	20
	Figure 2.8 Relay Output Connections.....	20
	Figure 2.9 Wiring Diagram of the Relay Out.....	20
2.7	LAN: Ethernet Connector	21
2.8	USB Ports	21

2.9	DVI and VGA Displays	21
2.10	Advanced Watchdog Timer	21
2.11	Expansion PCI & PCIE	22
2.12	VT-D	22
2.13	AMT	22
2.14	TPM	23

Chapter 3 Initial Setup..... 25

3.1	Configuration.....	26
	Figure 3.1 ECU-4784 Screw Locations	26
	Figure 3.2 ECU-4784 Removing the Top Cover.....	26
	Figure 3.3 ECU-4784 Open the Chassis Top Cover	27
3.2	Installing an M.2 PCIe Card	27
	Figure 3.4 M.2 PCIe Card Slot Location.....	27
	Figure 3.5 M.2 PCIe Card Slot Location (CN74)	28
3.3	Installing a USB Dongle	28
	Figure 3.6 Open the Chassis.....	28
	Figure 3.7 CN14 Location of the Internal USB Port.....	29
	Figure 3.8 CN37 Location of the Internal USB Port.....	29
3.4	Installing a Hard Disk	30
	Figure 3.9 SATA HDD Fixed Diagram	30
	Figure 3.10HDD Back Plate Location and SATA HDD Installation Diagram.....	31
	Figure 3.112 x SATA Signal and Power Connector Locations (CN41/43/75).....	32
3.5	Rack Installation.....	32
	Figure 3.12ECU-4784 Series Product Installation at the Rack Lo- cation.....	32
	Figure 3.13Installation Cabinet for the ECU-4784 Series	33
3.6	Installing the Expansion Card	34
3.7	BIOS Setup and System Assignments	35

Appendix A Pin Assignments 37

A.1	RS-232 Serial Ports (COM1 ~ COM2)	38
	Table A.1: COM (1~2) Port Pin Definitions	38
A.2	RS-232/422/485 Serial Ports (COM3 ~ COM10)	38
	Table A.2: RS-232/422/485 Serial Ports (COM3 ~ 10).....	38
	Table A.3: Relay Output Connector Pin Definitions.....	38
A.3	Relay Output Connector Pin Assignments.....	39
A.4	USB Connectors (USB1 ~ USB5).....	39
	Table A.4: USB Connector Pin Assignments.....	39
A.5	LAN Connectors (LAN1~LAN8)	40
	Table A.5: LAN Connector Pin Assignments	40
A.6	VGA Display Connector	40
	Table A.6: VGA Adapter Cable Pin Assignments	40
A.7	DVI Display Connector.....	41
	Table A.7: DVI Adapter Cable Pin Assignments.....	41
A.8	POWER Pin Assignments.....	42
	Table A.8: AC/DC Power Input PIN Definition / Définition du code PIN d'entrée d'alimentation CA/CC	42

Appendix B Watchdog Timer Programming 45

B.1	Watchdog Timer Programming	46
-----	----------------------------------	----

Appendix C BIOS Setup.....47

C.1	BIOS Setup and System Assignments.....	48
	Figure C.1 BIOS Setup Utility Main Screen.....	48
C.2	Entering Setup	49
C.2.1	Main Setup.....	49
	Figure C.2 Main Setup Screen	49
C.2.2	Advanced BIOS Features Setup.....	50
	Figure C.3 Advanced BIOS Features Setup Screen	50
	Figure C.4 ACPI Setting	51
	Figure C.5 Trusted Computing	52
	Figure C.6 CPU Configuration.....	53
	Figure C.7 SATA Configuration.....	54
	Figure C.8 PCH-FW Configuration.....	56
	Figure C.9 Firmware Update Configuration.....	57
	Figure C.10AMT Configuration	58
	Figure C.11USB Configuration	59
	Figure C.12Super I/O Configuration	60
	Figure C.13COM Port 1 Configuration.....	61
	Figure C.14COM Port 2 Configuration.....	62
	Figure C.15 Parallel Port Configuration	63
	Figure C.16PC Hardware Monitor.....	64
	Figure C.17iManager Configuration.....	64
	Figure C.18COM 3 Configuration	65
	Figure C.19COM Port 4 Configuration.....	66
	Figure C.20Hardware Monitor.....	67
	Figure C.21Serial Port Console Redirection	68
C.2.3	Chipset.....	69
	Figure C.22Chipset Setup.....	69
	Figure C.23PCH-IO Configuration	70
	Figure C.24PCI Express Configuration.....	71
	Figure C.25PCI Express Root Port 1 Configuration.....	72
	Figure C.26PCI Express Root Port 2 Configuration.....	73
	Figure C.27PCI Express Root Port 3 Configuration.....	74
	Figure C.28PCI Express Root Port 4 Configuration.....	75
	Figure C.29System Agent (SA) Configuration	76
	Figure C.30Graphics Configuration	77
	Figure C.31LCD Control	78
	Figure C.32Memory Configuration	79
C.2.4	Boot.....	80
	Figure C.33Boot Setup Utility.....	80
C.2.5	Security Setup.....	81
	Figure C.34Security Setup.....	81
C.2.6	Save & Exit	82
	Figure C.35Save & Exit.....	82

Appendix D Maintenance - RTC Battery 85

D.1	Maintenance - RTC Battery.....	86
-----	--------------------------------	----

Chapter 1

Overview

This chapter provides an overview of the ECU-4784 with 6th & 9th Gen Intel® Processor.

Sections include:

- Introduction
- Hardware Specifications
- Safety Precautions
- Block Diagram
- Chassis Dimensions
- Packing List

1.1 Introduction

Based on IEC 61850-3, a standard for the design of electrical substation automation, which defines communication between all Intelligent Electronic Devices (IED) and other related equipment from the process level (data acquisition, sensors, and actuators) to the bay level (protection, monitoring, and control tasks) and up to the station level (HMI/SCADA). Advantech's ECU-4784 Series can operate as a smart substation station level communication server, an HMI/SCADA workstation, a remote control station, a cybersecurity server, and an environmental status monitoring station. System integrators can thereby design an optimized digital substation while allowing energy operators to deliver electricity which is more secure, reliable, economical, and efficient.

Advantech's ECU-4784 Series is certified by IEC 61850-3 and IEEE 1613 to meet the harsh and critical requirements in smart grid automation. It provides high performance and reliable functionality to meet the most critical computing applications and helps reduce project deployment and maintenance costs. It supports remote monitoring and diagnosis for remote device connectivity to enhance management and maintenance efficiency. It is easy to expand domain I/O with its modular design, and it protects the system while meeting critical security application requirements.

High-Performance Computing Platforms for Power and Energy Automation Applications

- High-performance computing processors meet the most critical computing applications by utilizing Intel's VT-d technology, which can run multiple software applications. Energy operators can leverage virtual machine (VM) resources on the ECU-4784 to reduce project deployment costs.
- A highly integrated, all-in-one server platform to enhance smart substation station-level project deployment efficiency by integrating HMI visualization, monitoring, and control with the data concentrator and protocol converter to complete all station-level tasks. These functions are implemented through the different data collection gateways and the SCADA workstation.

Certification for Robust and Reliable Systems

- IEC 61850-3 and IEEE 1613 certification represent the highest reliability, designed to withstand vibration, electrical surges, fast transients, and extreme temperatures.
- The ECU-4784 Series supports TÜV IEC 61850-3 and IEEE 1613 certification. The ECU-4784 has a higher standard than other embedded automation controllers and contributes to greater reliability and stability. This makes it suitable for any global power and energy (P&E) automation market and harsh environments.
- The ECU-4784 Series is designed for applications in substations where it is subjected to significant electrical interference. Equipped with isolated power and isolated communication ports, the ECU-4784 Series has high resistance to electrical noise. It has been proven that it can work well in substations, but it is also suitable for other harsh applications.

Easy-to-Diagnose System & Communication with Enhanced Maintenance Efficiency

- Remotely monitor, diagnose, and manage systems to provide high system maintenance efficiency. Use Intel® AMT (built-in remote KVM) to quickly access a remote device desktop for diagnosis and troubleshooting without requiring on-site technical support.

Easy-to-Expand Domain I/O with Functional modules and Enhance Maintenance Efficiency

- Combined with two domain I/O slots to bring more flexible industrial applications, allowing customers to extend richer data collection and greater variety.
- The integrated functional module design is convenient for wiring, installation, and maintenance.

1.2 Hardware Specifications

Model	ECU-4784-C3xxx ECU-4784-E3xxx ECU-4784-E4xxx	ECU-4784-E5xxx	ECU-4784-G5xxx
General			
Certification	IEC 61850-3, IEEE 1613, CE, FCC class A, UL, CCC, CB, LVD		
Dimensions (W x D x H)	2U (440 x 280 x 88 mm / 17.3" x 8.6" x 3.4")		
Enclosure	SECC & Aluminum		
Mounting	2U Rack mount		
Input	100 ~ 240 V _{AC} or 100 ~ 240 V _{DC} ; 48V _{DC} optional with selectable power module		
Power Type	ATX, AT		
Weight	6.0 kg		
System Design	Fanless design		
OS Support	Windows 10, Windows Server 2016/2019, Linux		
System Hardware			
SOM	SOM-6897	SOM-5897	SOM-5899
CPU	3955U, i5-6300U, i7-6600U	E3-1505L v5	E-2276ML
Memory	DDR3L	DDR4	DDR4
Display	1 x DVI-D, 1 x DVI-I	1 x DVI-D, 1 x VGA	1 x DVI-D, 1 x DVI-I
Indicators	LEDs for Power, SSD, Programmable LED, LAN (Active, Status) and Serial (Tx, Rx)		
Storage	3 x 2.5" SATA SSD (RAID 0,1,5); 1 x M.2 PCIe	2 x 2.5" SATA SSD (RAID 0,1); 1 x CFast	3 x 2.5" SATA SSD (RAID 0,1,5); 1 x M.2 PCIe
Watchdog Timer	Programmable 256-level time intervals, from 1 to 255 seconds for each tier		
I/O Interface			
Serial Ports	2 x DB-9 RS-232 (9-wired), 8 x terminal block (5-wired), RS-422/485 (Automatic RS-485 data flow control) 2,000 V _{DC} isolation		
Serial Port Speed	(COM1 ~ COM2) RS-232: 50 ~ 115200 bps (COM3 ~ COM10) RS-422/485: 50 ~ 921600 bps		
LAN	1 x 10/100/1000 Base T RJ45 ports (Intel i219LM GbE Controller, AMT, Teaming Function, PXE) 7 x 10/100/1000 Base T RJ45 ports (Intel i210 GbE Controller, Teaming Function, PXE)		
USB	4 x USB, UHCI, rev 2.0 compliant (3 x rear,1 x internal) 2 x USB, UHCI, rev 3.0 compliant (2 x front)		
Expansion	2 x Domain I/O Expansions (Each Slot Supports up to 1 PCIe or 2 PCI devices)		
Relay Output	Form C, Contact 5 A @ 125 V _{AC} /5 A @ 30 V _{DC} (For IEC-61010-2-201)		
Programmable LED	8-ch programmable LED indicator		

1.3 Environment

- **Humidity:** 95% @ 40°C (non-condensing)
- **Operating Temperature:**
 - -25 ~ 70°C (-13 ~ 158° F) IEC 60068-2-1/2 with 100% CPU/I/O loading
 - -25 ~ 60°C (-13 ~ 140° F) IEC 60068-2-1/2 with 50% CPU/I/O loading (ECU-4784-E5/G5 Series)
- **Operating Humidity:** 20 ~ 95% (non-condensing)
- **Safety Cert. Temperature:** -20 ~ 50°C (-4 ~ 122° F)
- **Shock Protection:** 60068-2-27 CFast®: 50 G half sine, 11 ms HDD: 20 G half sine, 11 ms
- **Vibration Protection:** IEC 60068-2-64 (Random 1 Oct./min, 1 hr/axis.) CFast: 2 Grms @ 5 ~ 500 Hz, HDD: 1 Grms @ 5 ~ 500 Hz

1.4 Functional Block Diagram




Figure 1.1 ECU-4784 with 6th & 9th Gen Intel® Processor Functional Block

1.5 Safety Precautions

The following messages inform you of the details of how to make a connection. In most cases, you will simply need to connect a standard cable.

Warning!



Always disconnect the power cord from your chassis whenever you are working on it. Do not connect while the power is on. A sudden rush of power can damage sensitive electronic components. Only experienced electronics personnel should open the chassis.

Débranchez toujours le cordon d'alimentation de votre châssis chaque fois que vous travaillez dessus. Ne vous connectez pas lorsque l'appareil est sous tension. Une montée soudaine de puissance peut endommager les composants électroniques sensibles. Seul un personnel expérimenté en électronique doit ouvrir le châssis.

Caution!



Always ground yourself to remove any static electric charge before touching the device. ECU-4784 Series Modern electronic devices are very sensitive to static electric charges. Use a grounding wrist strap at all times. Place all electronic components on a static-dissipative surface or in a static-shielded bag.

Mettez-vous toujours à la terre pour éliminer toute charge électrique statique avant de toucher la série ECU-4784. Les appareils électroniques modernes sont très sensibles aux charges électriques statiques. Utilisez toujours un bracelet de mise à la terre. Placez tous les composants électroniques sur une surface antistatique ou dans un sac antistatique.

Note!



If DC voltage is supplied by an external circuit, please put a protection device in the power supply input port.

1.6 Chassis Dimensions




Figure 1.2 ECU-4784 Series Chassis Dimensions




Figure 1.3 ECU-4784 Series Exploded Diagram

Chapter 2

Hardware Function

This chapter shows how to setup the hardware functions, including connecting peripherals, setting jumpers and indicators.

Sections include:

- Overview
- LED Indicators
- Power Input
- RS-232 Interface
- RS-422/485 Interface
- Relay Out
- LAN: Ethernet Connector
- USB Ports
- DVI Display
- Advanced Watchdog Timer
- Expansion PCI & PCIE
- AMT
- TPM

2.1 Overview

The following figures show the indicators and connectors on the ECU-4784 Series. The following sections give you detailed information about the functions of each peripheral.

2.1.1 ECU-4784 LED and Interface Position




Figure 2.1 ECU-4784 Front Panel





Figure 2.2 ECU-4784 Rear Panel

2.2 LED Indicators

2.2.1 ECU-4784 LED Indicators

The LEDs in the front panel can be divided into 3 groups.



2.2.1.1 System Status Indicators



Table 2.1: Definition of System Status Indicators			
Item	LED	Status	Description
1	PWR1	Green	System power1 is on
		Off	System power1 is off
2	PWR2 (Optional)	Green	System power2 is on
		Off	System power2 is off
3	HDD	Green	Data being received/transmitted between storage devices
		Off	No Data being received/transmitted between storage devices
4	RESET		
5	ATX Button	ATX Button when Power on/off	

Note! Front Panel PWR2 LED is reserved for when the customer chooses a dual power supply.




2.2.1.2 LAN Status Indicators



ECU-4784 LAN LED status Indicators.

Table 2.2: Definition of LAN Status Indicators			
Item	LED	Status	Description
1	LAN/LINK (Port 1~8)	Green	1Gbps network link
		Orange	100Mbps network link
		Off	10Mbps network link or invalid network link
2	LAN/ACT (Port 1~8)	Green	Ethernet data being received/transmitted
		Off	No Ethernet data being received/transmitted

2.2.1.3 Serial Communication Status Indicators




ECU-4784 (10COM) Serial Communication Status Indicators:

Table 2.3: Definition of Serial COM Status Indicators

Item	LED	Status	Description
1	COM/Rx (Port 1 ~ 10)	Green	Serial port data being received
		Off	No data being received
2	COM/Tx (Port 1 ~ 10)	Orange	Serial port data being transmitted
		Off	No data being transmitted

2.2.1.4 Programmable LED




The ECU-4784 Series provides 8 programmable indicating LEDs, which are convenient for users to control the programmable LED states (green or off) by using API programming. They can be used to indicate and edit the machine's operating status. Refer to the product CD for more information.

Table 2.4: Programmable LED Status Indicators

LED	Status	Description
PL (0~7)	Green	Customers can, according to their needs, define the programmable LED state.
	Off	

There are up to 8 LEDs (LED0~LED7) that can control and monitor the status (On/Off). The Advantech programmable LED driver provides examples of how to use the ECU-4784's programmable LED and offers a reference for users developing their own applications. You can modify these sample applications to meet your requirements. You can find the example in the installation path below; it is located in the "C:\Program Files\Advantech\AdvPLED\Examples\VC++\PLEDTool" directory.



2.3 Power Input

The ECU-4784 Series products support single power input AC or DC.

Table 2.5: Power Input

Item	AC/DC	Volt. Range	Power Rating	Connector Type
PWR1	AC	100-240 V _{AC}	3.0 A 50-60 Hz	3Pin Screw Terminal
	DC	100-240 V _{DC}	3.0 A	3Pin Screw Terminal

The function of each part is described as below:




Figure 2.3 Power1 Input Location

Table 2.6: AC/DC Power Input PIN Definitions

Pin	Screen Printing	Function Description
1	L/V+	PWR1 L/PWR1 V+ AC/DC power input PIN
2	N/V-	PWR1 N/PWR1 V- AC/DC power input PIN
3		GND Provided adjacent to the main protective earthing terminal (IEC 60417-5019).

Make sure the voltage of the power source is correct and ensure the power outlet is connected to the earth.

Caution! *The earthing wire of the protective earthing conductor shall be green-and-yellow, 20 AWG (0.5 mm²), and connected to the building via an earthing connection.*





Le fil de terre du conducteur de protection est vert et jaune. (20 AWG/ 0,5 mm²) et doit être connecté au bâtiment avec connexion à la terre.

Caution! *The terminals for connecting protective earthing conductors shall comply with conductor size 1.0 (mm²). Minimum nominal thread diameter: 3.0 (mm) for Pillar type or stud type; 3.5 (mm) for Screw type.*



Les bornes de raccordement des conducteurs de protection doivent conforme à la taille du conducteur 1,0 (mm²), diamètre nominal minimum du filetage : 3,0 (mm) pour le type à pilier ou à goujon ; 3,5 (mm) pour le type à vis.

Table 2.7: Jumper Settings for ATX/AT Power Mode

	Jumper Setting	Description
CN67		AT Power Mode
	 (Default)	ATX Power Mode




Figure 2.4 AT X/AT Power Mode Select Location (CN67)

2.4 RS-232 Interface (COM1, COM2)

The ECU-4784 Series offers two standard RS-232 serial communication interface ports: COM1 and COM2. Please refer to A.1 for pin assignments. It can not support the IRQ, I/O address as the same as super I/O.

2.5 RS-232/422/485 Interface (COM3~COM10)

The ECU-4784 Series offers 8 x RS-232/422/485 serial communication interface ports: COM3 to COM10. Please refer to Appendix A.2 for their pin assignments. Users can select each port for RS-232 or RS-422/485 through different connections.

Table 2.8: Jumper Settings for RS-232/RS-422/RS-485 (For COM(3~10))

CNx		Description
CN16 CN17 CN18 CN19 CN20		RS-232
CN21 CN22 CN23		RS-422/485 (Default)

Table 2.9: Mapping Table of Jumpers for COM (3~10) Ports

COM Port	Jumper for RS-232/RS-422/RS-485 Selection
COM3	CN16
COM4	CN17
COM5	CN18
COM6	CN19
COM7	CN20
COM8	CN21
COM9	CN22
COM10	CN23

Table 2.10: Switch Settings for RS-422 Primary/Secondary Selection

		Description
SW2	OFF (default)	RS-422 Secondary Mode
	ON	RS-422 Primary Mode




Figure 2.5 COM3~10 Port-Related Jumper Locations (CN16-CN23)




Figure 2.6 COM3~10 Port-Related Jumper Locations (SW2)

2.5.1 UART Chips

ECU-4784 with 6th & 9th Gen Intel® processor comes with EXAR XR17V3581B UART containing 128-byte FIFO.

2.5.2 RS-422/485 Detection

In RS-422/485 mode, the ECU-4784 Series automatically detects a signal to match RS-422 or RS-485 networks (no jumper change required).

2.5.3 Automatic Data Flow Control Function for RS-485

In RS-485 mode, the ECU-4784 Series automatically detects the direction of incoming data. There is no handshake signal (e.g. RTS signal) necessary. This lets you conveniently build an RS-485 network with just two wires.

2.5.4 Terminal Resistor for RS-485

The onboard termination resistor (120-ohm / 300-ohm) for COM3~COM10 can be used for long-distance transmission or device matching (Default Open). Please refer to Table 2.8 for the mapping table for Jumpers and COM ports.

2.5.4.1 COM (3~10) RS-485 terminal resistor setting instructions






Table 2.11: Jumper Settings for Terminal Resistors (for COM (3~10))		
CNx		Description
CN27 CN28 CN29 CN30 CN31 CN32 CN33 CN34		Add 120-ohm terminal resistor on TX+/TX- of RS-485
		Add 300-ohm terminal resistor on TX+/TX- of RS-485
		Add 120-ohm terminal resistor on Rx+/Rx- of RS-422 (optional)
		Add 300-ohm terminal resistor on Rx+/Rx- of RS-422 (optional)

Table 2.12: Mapping Table of Jumpers for COM (3~10) Ports

COM Port	Jumper for Terminal Resistor
COM3	CN27
COM4	CN28
COM5	CN29
COM6	CN30
COM7	CN31
COM8	CN32
COM9	CN33
COM10	CN34

**Figure 2.7 COM3~10 Port-Related Jumper Locations (CN27-CN34)**

2.6 Relay Output For Events




Figure 2.8 Relay Output Connections




Figure 2.9 Wiring Diagram of the Relay Out

The ECU-4784 Series provides a relay out alarm function, which is convenient for the user to control the relay out alarm using the API. For a detailed explanation of the relay out API, please refer to:
C:\Program Files\Advantech\AdvRelay\Examples\VC++\RelayTool" directory.

Power1 Status	Power2 Status	Relay Out Function
OFF	OFF	NO COM NC
OFF	ON	Software control
ON	OFF	Software control
ON	ON	NO COM NC

Users can program the relay out function by API. The detailed parameters can be referred to in the software help document. The Advantech relay out driver provides examples, explaining how to use the ECU-4784 relay out with a series of real examples and reference information for users to develop their own applications. You can modify these sample applications to meet your needs. You can find the example in the below installation path:

C:\Program Files\Advantech\AdvRelay\Examples\VC++\RelayTool" directory.

2.7 LAN: Ethernet Connector

ECU-4784 Series products are equipped with Intel i219LM Gigabit LAN Ethernet controllers, which are compliant with IEEE802.3 1000Base-T, 100Base-TX and 10Base-T (802.3, 802.3u and 802.3ab). The products are also equipped with 7 Intel i210 Gigabit LAN network controllers, which are compliant with IEEE802.3u 10/100Base-T CSMA/CD standards. The Ethernet port provides a standard RJ-45 jack on board, and LED indicators on the front side to show its Link and Active status. Please note these LAN controllers all use PCI resources; the bandwidth or throughput may be restricted by the PCI bandwidth.

2.8 USB Ports

The ECU-4784 Series provides five USB interface connectors which provide complete Plug & Play and hot swapping for up to 127 external devices. It provides 2 x USB 3.0 ports on the front panel, and 3 USB 2.0 ports on the rear panel. It also provides 1 USB 2.0 port inside the chassis for a USB dongle key.

2.9 DVI and VGA Displays

The ECU-4784 Series is equipped with DVI-I and DVI-D. The resolution is up to 1920 x 1200 @60Hz. Please refer to the specification table in Chapter 1 for further information.

2.10 Advanced Watchdog Timer

The ECU-4784 Series provides one hardware watchdog timer for users to have a chance to escalate system status before a forced system reset. Users can operate system I/O ports 2E and 2F to set a different time. They can view the computer's interface or check Advantech's example in Appendix B.

2.11 Expansion PCI & PCIE

The ECU-4784 Series supports 2 standard domain I/O expansions which support up to 2 PCI devices and 1 PCIe device. Users can also expand other functions of the PCI & PCIe interface to meet their demands.

The ECU-4784 Series offers 2 expansion slots for modularized domain I/O plug-in cards. Through the interface card, the ECU-4784 Series can also use standard PCI cards, PCIe cards, mini-PCI cards as well as the PCI-104 card. Due to the ECU-4784 Series being an embedded system, the power provided to the expansion slot is limited. The maximum power support for each slot is:

5 V @ 2 A

3.3 V @ 1.5 A

12 V @ 0.25 A

There is support for a maximum 25W (at a 50°C condition) for all slots. Before you configure all the modules and plug-in cards, please note not to exceed the power limit.

2.12 VT-D

The ECU-4784 Series supports virtualization solutions, which allow multiple operating systems and applications to run in independent partitions, all on a single ECU-4784. Using virtualization capabilities, one physical computer system can function as multiple “virtual” systems. Intel® Virtualization Technology (Intel VT) improves the performance and robustness of today's virtual machine solutions by adding hardware support for efficient virtual machines. Intel® Virtualization Technology for Directed I/O (VT-d) extends Intel's Virtualization Technology (VT) roadmap by providing hardware assists for virtualization solutions. VT-d builds on the existing support for IA-32 (VT-x) and Itanium® processor (VT-i) virtualization, adding new support for I/O device virtualization. Intel VT-d can help end users improve the security and reliability of the systems, and also improve the performance of I/O devices in a virtualized environment. These inherently help IT managers reduce the overall total cost of ownership by reducing potential downtime and increasing productive throughput through better utilization of data center resources. For a step-by-step guide on how to enable VT-d and perform direct device assignment, you can refer to the ECU-4784 VT-d Help document for detailed instructions.

2.13 AMT

Intel® AMT is part of the Intel vPro technology offering. Platforms equipped with Intel® AMT can be managed remotely, regardless of whether they are powered up or whether they have a functioning OS.

The ECU-4784 Series supports AMT. You can see the step-by-step guide on how to enable the AMT function in the help guide.

2.14 TPM

The ECU-4784 Series supports Trusted Platform Module (TPM) technology. TPM is designed to provide hardware-based, security-related functions. A TPM is a microchip designed to provide basic security-related functions, primarily involving encryption keys. The TPM is usually installed on the motherboard of a computer, and communicates with the rest of the system using a hardware bus.

The Trusted Platform Module (TPM) is the root-of-trust in a given platform (such as on desktop computers). If built into a computer that runs an operating system that is aware of this chip, it can check the system integrity and authenticate third-party users who would like to access to the security features, while remaining under complete control of its primary user. Therefore, privacy and confidentiality are assured.

For a step-by-step guide on how to enable TPM and run TPM applications, you can refer to the ECU-4784 TPM help document for detailed information.

Chapter 3

Initial Setup

Sections include:

- Configuration
- Installing a CompactFlash Card
- Installing a USB Dongle
- Installing a Hard Disk
- Installation on a Rack
- BIOS Setup and System Assignments

3.1 Configuration

To open the ECU-4784 Series product chassis, follow the steps below:

1. Remove all power and signal connections.
2. Remove the screws as shown below.




Figure 3.1 ECU-4784 Screw Locations

3. Remove the chassis top cover:




Figure 3.2 ECU-4784 Removing the Top Cover

4. Open the chassis top cover. Users can set the COM port terminal resistor by jumper according to demand. For more detailed information, users should refer to chapter 2.5.




Figure 3.3 ECU-4784 Open the Chassis Top Cover

3.2 Installing an M.2 PCIe Card

The ECU-4784 Series provides 1 x M.2 PCIe card slot to install the cards:

1. Unscrew the 2 screws and remove the M.2 PCIe card back plate.




Figure 3.4 M.2 PCIe Card Slot Location

2. Insert the card at location (CN74) shown below.




Figure 3.5 M.2 PCIe Card Slot Location (CN74)

3.3 Installing a USB Dongle

The ECU-4784 Series provides a clamp for the USB dongle which can be installed inside the chassis. Follow these steps to install the USB dongle and clamp:

1. Refer to section 3.1 to open the chassis.




Figure 3.6 Open the Chassis

2. Plug the USB Dongle in the upper port of CN14. Note that the lower port is a dummy port.




Figure 3.7 CN14 Location of the Internal USB Port






Figure 3.8 CN37 Location of the Internal USB Port



3. Adjust the position of the kit to fasten the USB dongle, then screw to affix the kit.



3.4 Installing a Hard Disk

Follow the steps below to install an HDD:

1. To install an HDD and HDD bracket (in the accessory box).




Figure 3.9 SATA HDD Fixed Diagram

2. Unscrew the 2 screws and remove the HDD back plate.





Figure 3.10 HDD Back Plate Location and SATA HDD Installation Diagram

3. According to the schematic drawing, the HDD is directly installed on the device on the DIN-Rails (ECU-4784 supports up to 3 x HDD. The 3rd HDD location is on top as shown below).



4. The ECU-4784 series contains SATA and power cables for three SATA HDD in the chassis. The locations of the connectors are shown below; SATA signal connector and SATA power connectors are located on CN41/43/CN75.




Figure 3.11 2 x SATA Signal and Power Connector Locations (CN41/43/75)

3.5 Rack Installation

The ECU-4784 Series provides kits for rack mounting in the chassis.

1. Use the 4 screw holes to mount the ECU-4784 series on the rack.




Figure 3.12 ECU-4784 Series Product Installation at the Rack Location




Figure 3.13 Installation Cabinet for the ECU-4784 Series

Caution! *The ECU-4784 can only be used in a standard equipment cabinet with a minimum of 2Us available. The equipment cabinet must satisfy two requirements. (1) The maximum size of the cooling hole on the top, left, right, front and back is no more than 5mm. (2) There is no limit on the size of the hole on the bottom.*



L'ECU-4784 ne peut être utilisé que dans une armoire d'équipement standard avec un minimum de 2U disponibles. L'armoire d'équipement doit répondre à deux exigences. (1) La taille maximale du trou de refroidissement en haut, à gauche, à droite, à l'avant et à l'arrière ne dépasse pas 5 mm. (2) Il n'y a aucune limite sur la taille du trou au fond.


2. The ECU-4784 Series has aluminum fins on the top of the unit as heatsinks. They can generate natural convection for better heat transmission. To have optimal thermal performance, leave 2U (88.9 mm) space above the unit.

La série ECU-4784 est dotée d'ailettes en aluminium sur le dessus de l'unité comme dissipateur thermique. Il peut générer une convection naturelle pour une meilleure transmission de la chaleur. Pour avoir des performances thermiques optimales, laissez un espace de 2U (88,9 mm) au-dessus de l'unité.


3.6 Installing the Expansion Card

The ECU-4784 series provides two expansion slots for expansion card installation.


1. Unscrew the 2 screws and remove the two expansion back plates.



2. Plug in the PCI Card or PCIe card via the DIN-Rails.



3. Then secure the expansion cards using the previously removed screws.



3.7 BIOS Setup and System Assignments

The ECU-4784 with 6th & 9th Gen Intel® processor adopts Advantech's CPU module, and ECU-4784 with 6th & 9th Gen Intel® processor adopts Advantech's CPU module. Further information about the SOM module can be found in the SOM User Manual. You can find this manual on the companion disc or visit the website.

Please note that you can find detailed info on the BIOS Setup for ECU-4784-G5 as examples in Appendix C. For more information, please contact Advantech.

Appendix **A**

Pin Assignments

A.1 RS-232 Serial Ports (COM1 ~ COM2)




Table A.1: COM (1~2) Port Pin Definitions

Pins	RS-232
1	DCD
2	RXD
3	TXD
4	DTR
5	GND
6	DSR
7	RTS
8	CTS
9	RI

A.2 RS-232/422/485 Serial Ports (COM3 ~ COM10)






Table A.2: RS-232/422/485 Serial Ports (COM3 ~ 10)

Pins	RS-232	RS-422	RS-485
1	RxD	TX+	Data+
2	TxD	Tx-	Data-
3	RTS	RX+	
4	CTS	RX-	
5	GND	GND	GND


Table A.3: Relay Output Connector Pin Definitions

Pins	Definitions
NO	Normal OPEN
COM	COMMON Reference
NC	Normal CLOSE

Power Failure and Relay Out Functions

Power1 Status	Power2 Status	Relay Out Function
OFF	OFF	
OFF	ON	Software control
ON	OFF	Software control
ON	ON	

A.3 Relay Output Connector Pin Assignments



A.4 USB Connectors (USB1 ~ USB5)




Table A.4: USB Connector Pin Assignments

Pin	Signal	Cable Color
1	VCC	Red
2	DATA-	White
3	DATA+	Green
4	GND	Black

A.5 LAN Connectors (LAN1~LAN8)




Table A.5: LAN Connector Pin Assignments

Pin	Assignment	Description
1	TD+	Transmit +
2	TD-	Transmit -
3	RD +	Receive +
4	N/C	not used
5	N/C	not used
6	RD -	Receive -
7	N/C	not used
8	N/C	not used

A.6 VGA Display Connector




Table A.6: VGA Adapter Cable Pin Assignments

Pin	Signal
1	RED
2	GREEN
3	BLUE
4	N/C
5	GND
6	GND
7	GND
8	GND
9	VCC
10	GND
11	N/C
12	VGA_SDA
13	HSYNC
14	VSYNC
15	VGA_SCL

A.7 DVI Display Connector




Table A.7: DVI Adapter Cable Pin Assignments

Pin	Signal
1	TMDS_C2#
2	TMDS_C2
3	GND
4	CRT_DDC_CLK
5	CRT_DDC_DATA
6	MDVI_CLK
7	MDVI_DATA
8	VGA_VSY
9	TMDS_C1#
10	TMDS_C1
11	GND
12	-
13	-
14	VCC_DVI
15	VGA Detect
16	HP_DET
17	TMDS_C0#
18	TMDS_C0
19	GND
20	-
21	-
22	GND
23	TMDS_CK#
24	TMDS_CK
25	VGAR
26	VGAG
27	VGAB
28	VGAHSY
29	GND

A.8 POWER Pin Assignments




Table A.8: AC/DC Power Input PIN Definition / Définition du code PIN d'entrée d'alimentation CA/CC

Pin / Broché	Screen Printing / Impression d'écran	Function Description / Description de la fonction
1	L/V+	PWR1 L/PWR1 V+ AC/DC power input PIN / Broche d'entrée d'alimentation PWR1 L/V + AC/DC
2	N/V-	PWR1 N/PWR1 V- AC/DC power input PIN / PWR1 N/V-broche d'entrée d'alimentation AC/DC
3	⊕	GND Provided adjacent to the main protective earthing terminal (IEC 60417-5019). / Fourni à côté de la borne de mise à la terre de protection principale (CEI 60417-5019).

Make sure the voltage of the power source is correct and ensure the power outlet is connected to the earth. / Assurez-vous que la tension de la source d'alimentation est correcte avant d'assurer la prise de courant avec la connexion à la terre.

Caution! The earthing wire of the protective earthing conductor should be green-and-yellow, 20 AWG/0.5 mm², connected to the building with an earthing connection.



Le fil de terre du conducteur de protection est vert et jaune. (20 AWG/ 0,5 mm²) et doit être connecté au bâtiment avec connexion à la terre.

Caution! *The terminals for connecting protective earthing conductors shall comply with Conductor size 1.0 (mm²), Minimum nominal thread diameter: 3.0 (mm) for Pillar type or stud type; 3.5 (mm) for Screw type.*



Les bornes de raccordement des conducteurs de protection doivent conforme à la taille du conducteur 1,0 (mm²), diamètre nominal minimum du filetage : 3,0 (mm) pour le type à pilier ou à goujon; 3,5 (mm) pour le type à vis.

Note! *If the customer wants to use a dual power supply, refer to Table2.1 for power input specifications.*



Appendix **B**

Watchdog Timer Programming

B.1 Watchdog Timer Programming

```
-----  
-----  
Enter the extended function mode, interruptible double-write  
-----
```

```
----- MOV DX,2EH  
MOV AL,87H OUT DX,AL OUT DX,AL  
-----
```

```
-----  
Configured logical device 8, configuration register CRF6  
-----
```

```
----- MOV DX,2EH  
MOV AL,2BH OUT DX,AL MOV DX,2FH IN AL,DX  
AND AL,0EFH; Setbit 4=0 Pin 89=WDTO OUT DX,AL  
MOV DX,2EH  
MOV AL,07H; point to Logical Device Number Reg. OUT DX,AL  
MOV DX,2FH  
MOV AL,08H; select logical device 8 OUT DX,AL;  
MOV DX,2EH  
MOV AL,30H;Set watch dog activate or inactivate OUT DX,AL  
MOV DX,2FH  
MOV AL,01H; 01:activate 00:inactivate OUT DX,AL;  
MOV DX,2EH  
MOV AL,F5H; Setting counter unit is second OUT DX,AL  
MOV DX,2FH MOV AL,00H OUT DX,AL; MOV DX,2EH MOV AL,F6H OUT  
DX,AL MOV DX,2FH  
MOV AL,05H; Set 5 seconds
```

```
OUT DX,AL  
;-----  
; Exit extended function mode  
;----- MOV DX,2EH  
MOV AL,AAH OUT DX,AL
```

Appendix **C**

BIOS Setup

C.1 BIOS Setup and System Assignments

AMIBIOS has been integrated into many motherboards for over a decade. With the AMIBIOS Setup program, users can modify BIOS settings and control the various system features. This chapter describes the basic navigation of the BIOS setup screens. The ECU-4784 with 6th & 9th Gen Intel processor adopts Advantech's core CPU module. Further information about the SOM module can be found in the SOM user manual.




Figure C.1 BIOS Setup Utility Main Screen

AMI's BIOS ROM has a built-in Setup program that allows users to modify the basic system configuration. This information is stored in flash ROM so it retains the Setup information when the power is turned off.

C.2.2 Advanced BIOS Features Setup

Select the Advanced tab from the ECU-4784 setup screen to enter the Advanced BIOS Setup screen. Users can select any item in the left frame of the screen, such as CPU Configuration, to go to the sub-menu for that item. Users can display an Advanced BIOS Setup option by highlighting it using the <Arrow> keys. All Advanced BIOS Setup options are described in this section. The Advanced BIOS Setup screens are shown below. The sub-menus are described on the following pages.




Figure C.3 Advanced BIOS Features Setup Screen

C.2.2.1 ACPI Settings




Figure C.4 ACPI Setting

- **Enable ACPI Auto Configuration**
This item allows users to enable or disable BIOS ACPI auto configuration.
- **Enable Hibernation**
This item allows users to enable or disable hibernation.
- **ACPI Sleep State**
This item allows users to set the ACPI sleep state.
- **Lock Legacy Resources**
This item allows users to lock legacy devices resources.
- **S3 Video Repost**
Enable or Disable S3 Video Repost.
- **ACPI Low Power S0 Idle**
This item allows users to enable or disable ACPI Low Power S0 Idle support.

C.2.2.2 Trusted Computing




Figure C.5 Trusted Computing

- **Security Device Support**
This item allows users to enable or disable BIOS support for security device support, and the OS will not show the Security Device. TCG EFI Protocol and INT1A interface will not be available.

C.2.2.3 CPU Configuration




Figure C.6 CPU Configuration

- **Hyper-threading**
Enable for Windows XP and Linux (OS optimized for Hyper-Threading Technology) and Disable for other OS (OS not optimized for Hyper-Threading Technology) and Disable for other OS (OS not optimized for Hyper-Threading Technology). When Disabled, only one thread per core is enabled.
- **Active Processor Cores**
This item allows users to enable a number of cores in each processor package.
- **Limit CPUID Maximum**
Disable for Windows XP.
- **Execute Disable Bit**
This item allows users to enable or disable Execute Disable Bit.
XD can prevent certain classes of malicious buffer overflow attacks when combined with a supporting OS (Windows server 2003 SP1, Windows XP SP2 SuSE Linux 9.2, RedHat Enterprise 3 update 3.)
- **Intel Virtualization Technology**
This item allows users to enable or disable Intel Virtualization Technology.
When enabled, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology.
- **Hardware Prefetcher**
This item allows users to enable or disable Hardware Prefetcher. Enable the Mid Level Cache (L2) streamer prefetcher.
- **Adjacent Cache Line Prefetch**
This item allows users to enable or disable Adjacent Cache Line Prefetch. Enable the Mid Level Cache (L2) prefetching of adjacent cache lines.

- **CPU AES**
This item allows users to enable or disable CPU Advanced Encryption Standard instructions.
- **Boot performance mode**
This Item allows users to select the performance state that the BIOS will set before OS handoff.
- **EIST**
This item allows users to enable or disable Intel SpeedStep.
- **Turbo Mode**
This item allows users to enable or disable Turbo Mode.
- **Energy Performance**
This Item allows users to optimize between performance and power savings.
- **CPU C states**
This item allows users to enable or disable CPU C states.
- **ACPI CTPD BIOS**
This item allows users to enable or disable ACPI CTPD BIOS support.
- **Configurable TDP Level**
This Item allows users to select Configurable TDP Level.
Allow re-configuration of TDP levels based on current power and thermal delivery capabilities of the system.
- **Config TDP Lock**
This item allows users to enable or disable Config TDP Lock. It locks the Config TDP Control register.

C.2.2.4 SATA Configuration




Figure C.7 SATA Configuration

- **SATA Controller(s)**
This item allows users to enable or disable SATA devices.
- **SATA Mode Selection**
This item allows users to select SATA mode selection. (Determines how SATA controller(s) operate)
- **Aggressive LPM Support**
This item allows users to enable or disable PCH to aggressively enter link power state.
- **SATA Controller Speed**
Indicates the maximum speed the SATA controller can support.
- **SATA Port 0 DevSlp**
Enable/Disable SATA Port 0 DevSlp. For DevSlp to work, both hard drive and SATA Ports need to support DevSlp function; otherwise an unexpected behavior might happen. Please check the board design before enabling it.
- **Serial ATA Port 1**
Software Preserve
 - Port 1
Enable or Disable SATA Port.
 - SATA Device Type
Identify the SATA port that is connected to the Solid State Drive or Hard Disk Drive.
 - SATA Port 1 DevSlp
Enable/Disable SATA Port 1 DevSlp. For DevSlp to work, both hard drive and SATA Port need to support DevSlp function; otherwise, an unexpected behavior might happen. Please check the board design before enabling it.
- **Serial ATA Port 2**
Software Preserve
 - Port 2
Enable or Disable SATA Port.
 - SATA Device Type
Identify the SATA port is connected to solid state Driver or Hard Disk Drive.
 - SATA Port 2 DevSlp
Enable/Disable SATA Port 2 DevSlp. For DevSlp to work, both hard drive and SATA Ports need to support the DevSlp function; otherwise, an unexpected behavior might happen. Please check the board design before enabling it.
- **Serial ATA Port 3**
Software Preserve
 - Port 3
Enable or Disable SATA Port.
 - SATA Device Type
Identify the SATA port is connected to solid state Driver or Hard Disk Drive.
 - SATA Port 3 DevSlp
Enable/Disable SATA Port 3 DevSlp. For DevSlp to work, both hard drive and SATA Port need to support DevSlp function; otherwise, an unexpected behavior might happen. Please check the board design before enabling it.

C.2.2.5 PCH-FW Configuration




Figure C.8 PCH-FW Configuration

- **MDES BIOS Status Code**
This item allows users to enable or disable MDES BIOS status code.
- **TPM Device Selection**
This item allows users to enable or disable TPM Device Selection. (PTT or dTPM. PTT-Enables PTT in SkuMgr dTPM 1.2- Disables PTT in SkuMgr. Warning!: PTT/dTPM will be disabled and all data saved on it will be lost.
- **Firmware Update Configuration**
Configure Management Engine Technology Parameters

Firmware Update Configuration




Figure C.9 Firmware Update Configuration

- **ME FW Image Re-Flash**
This item allows users to enable or disable ME FW Image Re-Flash function.

C.2.2.6 AMT Configuration




Figure C.10 AMT Configuration

■ Intel® AMT

This item allows users to enable or disable Intel AMT (Active Management Technology) BIOS Extension.

Note! *iAMT H/W is always enabled. This option just controls the BIOS extension execution. If enabled, this requires additional firmware in the SPI device.*



■ BIOS Hotkey Pressed

This item allows users to enable or disable BIOS Hotkey Pressed.

■ MEBx Selection Screen

This item allows users to enable or disable MEBx Selection Screen.

■ Hide Un-Configure ME Confirmation

This item allows users to hide un-configure ME without password confirmation prompt.

■ MEBx Debug Message Output

This item allows users to enable or disable MEBx Debug Message Output.

■ Un-Configure ME

This item allows users to enable or disable Un-Configure ME.

■ Amt Wait Timer

This item allows users to set timer to wait before sending ASF_GET_BOOT_OPTIONS.

■ Disable ME

This item allows users to set ME to Soft Temporary disabled.

■ ASF

This item allows users to enable or disable Alert Specification Format.

- **Activate Remote Assistance Process**
This item allows users to enable or disable Activate Remote Assistance Process. To Trigger CIRA boot.
- **USB Configure**
This item allows users to enable or disable USB Configure function.
- **PET Progress**
This item allows users to enable or disable PET Events progress to receive PET events or not.
- **WatchDog**
This item allows users to enable or disable the WatchDog.

C.2.2.7 USB Configuration




Figure C.11 USB Configuration

- **Legacy USB Support**
Enables the support for legacy USB. Auto option disables legacy support if no USB devices are connected. Auto option disables legacy support if no USB devices are connected. Disable option will keep USB devices available only for EFI applications.
- **USB3.0 Support**
This item allows users to enable or disable USB3.0 (XHCI) controller support.
- **XHCI Hand-off**
This item allows users to enable or disable XHCI Hand-off.
This is a workaround for OS without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.
- **EHCI Hand-off**
This item allows users to enable or disable EHCI Hand-off.

This is a workaround for OS without EHCI hand-off support. The EHCI ownership change should be claimed by EHCI driver.

- **USB Mass Storage Driver Support**

This item allows users to enable or disable USB Mass Storage Driver Support.

- **USB transfer time-out**

This item allows users to select time-out section.

The time-out value for control, bulk, and interrupt transfers.

- **Device reset time-out**

This item allows users to select device time-out section. USB mass storage devices start unit command time-out.

- **Device power-up delay**

This item allows users to select device power-up section.

Maximum time the device will take before it properly reports itself to the Host controller. "Auto" uses a default value: for a Root port it is 100ms, for a Hub port the delay is taken from the Hub descriptor.

- **USB2.0 FlashDisk1.00**

This item allows users to select USB2.0 FlashDisk1.00 section.

Mass storage device emulation type. "Auto" enumerates devices according to their media format. Optical drives are emulated as "CDROM" drives with no media will be emulated according to a drive type.

C.2.2.8 Super IO Configuration




Figure C.12 Super I/O Configuration

- **COM Port 1 Configuration**

This item allows user to set Parameters of COM Port 1.

- **COM Port 2 Configuration**

This item allows user to set Parameters of COM Port 2.

- **Parallel Port Configuration**
This item allows users to set Parameters of Parallel Port (LPT/LPTE).
- **Hardware Monitor**
This item allows user to change monitor hardware status.

COM Port 1 Configuration




Figure C.13 COM Port 1 Configuration

- **COM Port 1**
This item allows users to enable or disable the COM Port.
- **Change settings**
This item allows users to select an optimal setting for Super I/O device.

COM Port 2 Configuration



Figure C.14 COM Port 2 Configuration

- **COM Port 2**
This item allows users to enable or disable the COM Port.
- **Change settings**
This item allows users to select an optimal setting for the Super IO device.
- **Device Mode**
This item allows users to change the Serial Port mode. Select <High Speed> or <Normal Mode> mode.

Parallel Port Configuration




Figure C.15 Parallel Port Configuration

- **Parallel Port**
This item allows users to enable or disable Parallel Port (LPT/LPTE).
- **Change settings**
This item allows users to select an optimal setting for the Super IO device.
- **Device Mode**
This item allows users to change the Printer Port mode.

Hardware Monitor




Figure C.16 PC Hardware Monitor

This item monitors hardware status.

C.2.2.9 iManager Configuration




Figure C.17 iManager Configuration

- **CPU Shutdown Temperature**
This item allows users to select CPU Shutdown Temperature.
- **iManager Smart Fan - COM Module**
This item allows users to enable or disable iManager Smart Fan - COM Module. To control iManager Smart FAN function.
- **iManager Smart Fan - Carrier Board**
This item allows users to enable or disable iManager Smart Fan - Carrier Board. To control iManager Smart FAN Carrier Board function.
- **iManager WatchDog IRQ**
This item allows users to select iManager IRQ number eBrain WatchDog.
- **Backlight Enable Polarity**
This item allows users to switch Backlight Enable Polarity for Native or Invert.
- **Power Saving Mode**
This item allows users to select ITE8528 Power Saving Mode.

COM Port 3 Configuration




Figure C.18 COM 3 Configuration

- **COM Port 3**
This item allows users to enable or disable COM Port.
- **Change settings**
This item allows users to select an optimal setting for the Super IO device.
- **Device Mode**
This item allows users to change the Serial Port mode. Select <High Speed> or <Normal mode> mode.

COM Port 4 Configuration




Figure C.19 COM Port 4 Configuration

- **COM Port 4**
This item allows users to enable or disable a COM Port.
- **Change settings**
This item allows users to select an optimal setting for the Super IO device.
- **Device Mode**
This item allows users to change the Serial Port mode. Select <High Speed> or <Normal mode> mode.

Hardware Monitor




Figure C.20 Hardware Monitor

This item monitor hardware status.

C.2.2.10 Serial Port Console Redirection




Figure C.21 Serial Port Console Redirection

- **COM1 Console Redirection**
This item allows users to enable or disable Console Redirection.
- **COM2 Console Redirection**
This item allows users to enable or disable Console Redirection.
- **COM3 Console Redirection**
This item allows users to enable or disable Console Redirection.
- **COM4 Console Redirection**
This item allows users to enable or disable Console Redirection.
- **EMS Console Redirection**
This item allows users to enable or disable Console Redirection.

C.2.3 Chipset

Select the Chipset tab from the ECU-4784 setup screen to enter the Chipset BIOS Setup screen. You can display a Chipset BIOS Setup option by highlighting it using the <Arrow> keys. All Plug and Play BIOS Setup options are described in this section. The Plug and Play BIOS Setup screen is shown below.



Figure C.22 Chipset Setup

- **PCH-IO Configuration**
This item allows users to change PCH Parameters.
- **System Agent (SA) Configuration**
This item allows users to change System Agent (SA) Parameters.

C.2.3.1 PCH-IO Configuration




Figure C.23 PCH-IO Configuration

- **PCI Express Configuration**
This item allows users to change PCI Express Configuration settings.
- **SATA And RST Configuration**
This item allows users to change **SATA And RST Configuration** settings.
- **USB Configuration**
This item allows users to change USB XHCI Compliance Mode settings.
- **Security Configuration**
This item allows users to change **Security** Configuration settings.
- **HD Audio Configuration**
This item allows users to change **HD Audio** Configuration settings.
- **SerialIO Configuration**
This item allows users to change **SerialIO** Configuration settings.
- **SCS Configuration***
This item allows users to change **SCS SDHC 3.0 Controller** settings.
- **PCH LAN Controller**
This item allows users to enable or disable onboard NIC.
- **Wake on LAN**
This item allows users to enable or disable integrated LAN to wake the system.
(The Wake on LAN cannot be disabled if ME is not in the Sx State.)
- **Serial IRQ Mode**
Configure Serial IRQ Mode to [Continuous] or [Quiet].
- **State After G3**
Specify what state to go to when power is re-applied after failure (G3 state): [S0 state] or [S5 state].

C.2.3.1.1 PCI Express Configuration



Figure C.24 PCI Express Configuration

- **PCI Express Clock Gating**
This item allows users to enable or disable PCI Express Clock Gating for each root port.
- **DMI Link ASPM Control**
This item allows users to enable or disable DMI Link ASPM Control.
The Control of Active State Power Management on both NB side and SB side of the DMI Link.
- **PCI Express Root Port 1**
This item allows users to change PCI Express Root Port 1 settings.
- **PCI Express Root Port 2**
This item allows users to change PCI Express Root Port 2 settings.
- **PCI Express Root Port 3**
This item allows users to change PCI Express Root Port 3 settings.
- **PCI Express Root Port 4**
This item allows users to change PCI Express Root Port 4 settings.

PCI Express Root Port 1 Configuration




Figure C.25 PCI Express Root Port 1 Configuration

- **PCI Express Root Port 1**
This item allows users to enable or disable the PCI Express Root Port.
- **ASPM Support**
This item allows users to set the ASPM level. Force L0s- Force all links to L0s state.
Auto-BIOS auto configure Disable- disables ASPM L1 Substates
This item allows users to change L1 Substates settings.
- **Hot Plug**
This item allows users to enable or disable Hot Plug.
- **PCIe Speed**
This item allows users to select PCIe Speed.

PCI Express Root Port 2 Configuration




Figure C.26 PCI Express Root Port 2 Configuration

- **PCI Express Root Port 2**
This item allows users to enable or disable PCI Express Root Port.
- **ASPM Support**
This item allows users to set the ASPM level.
Force L0s- Force all links to L0s state. Auto-BIOS auto configure.
Disable- disables ASPM.
- **Hot Plug**
This item allows users to enable or disable Hot Plug.
- **PCIe Speed**
This item allows users to select PCIe Speed.

PCI Express Root Port 3 Configuration




Figure C.27 PCI Express Root Port 3 Configuration

- **PCI Express Root Port 3**
This item allows users to enable or disable PCI Express Root Port.
- **ASPM Support**
This item allows users to change L1 Substates settings.
- **Hot Plug**
This item allows users to enable or disable Hot Plug.
- **PCIe Speed**
This item allows users to select PCIe Speed.

PCI Express Root Port 4 Configuration




Figure C.28 PCI Express Root Port 4 Configuration

- **PCI Express Root Port 4**
This item allows users to enable or disable PCI Express Root Port.
- **ASPM Support**
This item allows users to change L1 Substates settings.
- **Hot Plug**
This item allows users to enable or disable Hot Plug.
- **PCIe Speed**
This item allows users to select PCIe Speed.

C.2.3.2 System Agent (SA) Configuration




Figure C.29 System Agent (SA) Configuration

- **VT-D**
This item allows users to enable or disable the VT-d function.
- **Graphics Configuration**
This item allows users to change graphics settings.
- **Memory Configuration**
This item allows users to change memory configuration parameters.

C.2.3.2.1 Graphics Configuration




Figure C.30 Graphics Configuration

- **Primary Display**
This item allows users to select which of IGFX/PEG/PCI Graphics device should be the Primary display or select SG for Switchable Gfx.
- **Internal Graphics**
This item keeps IGD enabled based on the setup options.
- **Aperture Size**
This item allows users to change Aperture Size.
- **DVM T Pre-Allocated**
This item allows users to select DVM T 5.0 Pre-allocated (fixed) graphics memory size used by the internal graphics device.
- **DVM T Total Gfx Mem**
This item allows users to select DVM T 5.0 total graphics memory size used by the internal graphics device.

LCD Control




Figure C.31 LCD Control

This item allows users to perform LCD control.

C.2.3.2.2 Memory Configuration




Figure C.32 Memory Configuration

■ Memory Information

This item shows memory configuration parameters.

C.2.4 Boot




Figure C.33 Boot Setup Utility

- **Setup Prompt Timeout**
This item allows users to select the number of seconds to wait for the setup activation key.
- **Bootup NumLock State**
Select the keyboard NumLock state.
- **Quiet Boot**
This item allows users to enable or disable Quiet Boot option.
- **Fast Boot**
This item allows users to enable or disable boot with initialization of a minimal set of devices required to launch active boot option. It has no effect for BBS boot options.
- **Boot Option #1**
This item allows users to set the system boot order.

C.2.5 Security Setup




Figure C.34 Security Setup

All Security Setup options, such as password selection are described in this section. To access the sub-menu for the following items, select the item and press <Enter>:

- **Change Administrator/User Password**

Select this option and press <ENTER> to access the sub-menu, and then type in the password.

C.2.6 Save & Exit




Figure C.35 Save & Exit

- **Save Changes and Exit**
When users have completed system configuration, select this option to save changes, exit the BIOS setup menu and reboot the computer if necessary for all system configuration parameters to take effect.
- **Discard Changes and Exit**
Select this option to quit Setup without making any permanent changes to the system configuration.
- **Save Changes and Reset**
When users have completed system configuration, select this option to save changes, exit the BIOS setup menu, and reboot the computer for all configuration parameters to take effect.
- **Discard Changes and Reset**
Select this option to quit Setup without making any permanent changes to the system configuration and reboot the computer.
- **Save Changes**
When users have completed system configuration, select this option to save changes without exiting the BIOS setup menu.
- **Discard Changes**
Select this option to discard any current changes and load the previous system configuration.
- **Restore Defaults**
The ECU-4784 automatically configures all setup items to optimal settings when users select this option. Optimal Defaults are designed for maximum system performance, but may not work best for all computer applications. In particular,

do not use the Optimal Defaults if the users computer is experiencing system configuration problems.

- **Save User Defaults**

When users have completed system configuration, select this option to save changes as user defaults without exiting the BIOS setup menu.

- **Restore User Defaults**

The users can select this option to restore user defaults.

- **Boot Override**

This item allows users to choose the boot device.

Appendix **D**

Maintenance - RTC
Battery


D.1 Maintenance - RTC Battery

1. A CMOS battery is inside ECU-4784 and needs to be maintained and changed when it runs out of power.
2. Battery Model: BR2032
3. Battery Lifecycle:
The CMOS battery will be consumed when the system is powered off.
The lifecycle of the battery will vary with different conditions.


For system remain powered off: 3 years

For system remain powered on: 10 years

4. Changing the battery.
To change the battery, please prepare a new BR2032 and following the instruction below.
Step 1: Open the chassis of the system by losing the screws marked in red.



Step 2: Remove the RTC battery on the board marked in red and change with the new battery.





Enabling an Intelligent Planet

www.advantech.com

Please verify specifications before quoting. This guide is intended for reference purposes only.

All product specifications are subject to change without notice.

No part of this publication may be reproduced in any form or by any means, such as electronically, by photocopying, recording, or otherwise, without prior written permission from the publisher.

All brand and product names are trademarks or registered trademarks of their respective companies.

© Advantech Co., Ltd. 2025