

How to use RS-232/422

- First, it is necessary to change the switch





Table 2.6 :COM Port Mode Selection

| | Mode/Description | Pin1 | Pin2 | Pin3 | Pin4 |
|---|--|------|------|--|----------------------------------|
| | RS-232 | OFF | OFF | OFF | OFF |
| | RS-422 | ON | OFF | ON: TerminationEnable OFF: TerminationDisable | OFF |
| COM1_SW1 (COM1) COM2_SW1 (COM2) COM4_SW1 (COM3) COM5_SW1 (COM4) Setting | RS-485 (Software flow control) | ON | ON | ON: TerminationEnable OFF: TerminationDisable | ON |
| | RS-485 (Hardware flow control) TerminationEnable | ON | ON | ON: TerminationEnable OFF: TerminationDisable | ON: Receiver OFF: Transmitter |

How to use RS-232/422

- First, customer need to change the switch to RS-232/422, then use the following command:
 - \$ sudo -s
 - # stty -F /dev/ttyTHS<UARD_NO> speed 115200
- Receive data:
 - # cat /dev/ttyTHS<UARD_NO>
- Transmit data:
 - # echo “hello” > /dev/ttyTHS<UARD_NO>

How to use RS-485-Hardware

- First, it is necessary to change the switch





Table 2.6 :COM Port Mode Selection

| | Mode/Description | Pin1 | Pin2 | Pin3 | Pin4 |
|---|--|------|------|--|----------------------------------|
| | RS-232 | OFF | OFF | OFF | OFF |
| | RS-422 | ON | OFF | ON: TerminationEnable OFF: TerminationDisable | OFF |
| COM1_SW1 (COM1) COM2_SW1 (COM2) COM4_SW1 (COM3) COM5_SW1 (COM4) Setting | RS-485 (Software flow control) | ON | ON | ON: TerminationEnable OFF: TerminationDisable | ON |
| | RS-485 (Hardware flow control) TerminationEnable | ON | ON | ON: TerminationEnable OFF: TerminationDisable | ON: Receiver OFF: Transmitter |

How to use RS-485-Hardware

- Also, customer can change the switch to RS-485 mode and change the speed of RS-485 by following command
 - \$ sudo -s
 - # stty -F /dev/ttyTHS<SEND_UARD_NO> speed 115200
 - # stty -F /dev/ttyTHS<REC_UARD_NO> speed 115200
- Receive data:
 - # cat /dev/ttyTHS<REC_UARD_NO>
- Transmit data:
 - # echo "hello" > /dev/ttyTHS<SEND_UARD_NO>

How to use RS-485-Hardware

- COM1 Send and COM4 Recieve



```
root@linux: /home/ubuntu/Desktop
To run a command as administrator (user "root"), use "sudo <command>".
See "man sudo_root" for details.

ubuntu@linux:~/Desktop$ sudo -s
[sudo] password for ubuntu:
root@linux: /home/ubuntu/Desktop# stty -F /dev/ttyTHS
ttyTHS0 ttyTHS1 ttyTHS3 ttyTHS4
root@linux: /home/ubuntu/Desktop# stty -F /dev/ttyTHS0
speed 9600 baud; line = 0;
-brkint -imaxbel
root@linux: /home/ubuntu/Desktop# stty -F /dev/ttyTHS0 speed 115200
9600
root@linux: /home/ubuntu/Desktop# stty -F /dev/ttyTHS1 speed 115200
9600
root@linux: /home/ubuntu/Desktop# cat /dev/ttyTHS1 &
[1] 2347
root@linux: /home/ubuntu/Desktop# echo "1234" > /dev/ttyTHS0
1234
root@linux: /home/ubuntu/Desktop# echo "1234" > /dev/ttyTHS0
1234
root@linux: /home/ubuntu/Desktop#
```


How to use RS-485-Hardware

- First, it is necessary to change the switch





Table 2.6 :COM Port Mode Selection

| | Mode/Description | Pin1 | Pin2 | Pin3 | Pin4 |
|---|---|------|------|--|----------------------------------|
| | RS-232 | OFF | OFF | OFF | OFF |
| | RS-422 | ON | OFF | ON: Termination Enable OFF: Termination Disable | OFF |
| COM1_SW1 (COM1) COM2_SW1 (COM2) COM4_SW1 (COM3) COM5_SW1 (COM4) Setting | RS-485 (Software flow control) | ON | ON | ON: Termination Enable OFF: Termination Disable | ON |
| | RS-485 (Hardware flow control) Termination Enable | ON | ON | ON: Termination Enable OFF: Termination Disable | ON: Receiver OFF: Transmitter |

How to use RS-485-Software

- we need to enable the RTS Pin by following command:
 - \$ sudo -s
 - # echo 460 > /sys/class/gpio/export
 - # echo 477 > /sys/class/gpio/export

| RTS Pin Number | AIR-030 JP 5.1.1 |
|----------------|------------------|
| COM1 | 460(PR.04) |
| COM2 | 477(PY.07) |
| COM3 | 396(PH.05) |
| COM4 | 468(PX.06) |

How to use RS-485-Software

- Control direction by RTS Pin by following command:
 - # echo out > /sys/class/gpio/PR.04/direction
 - # echo out > /sys/class/gpio/PY.07/ direction
- Set the COM ports speed:
 - # stty -F /dev/ttyTHS0 speed 115200 -crtcts
 - # stty -F /dev/ttyTHS4 speed 115200 -crtcts

| RTS Pin Number | AIR-030 JP 5.1.1 |
|----------------|------------------|
| COM1 | 460(PR.04) |
| COM2 | 477(PY.07) |
| COM3 | 396(PH.05) |
| COM4 | 468(PX.06) |

How to use RS-485-Software

- Receive data: (pull low to receive data)
 - # echo 0 > /sys/class/gpio/PR.04/value
 - # cat /dev/ttyTHS0
- Transmit data: (pull high to send data)
 - # echo 1 > /sys/class/gpio/PY.07/value
 - # echo "hello" > /dev/ttyTHS4

| RTS Pin Number | AIR-030 JP 5.1.1 |
|----------------|------------------|
| COM1 | 460(PR.04) |
| COM2 | 477(PY.07) |
| COM3 | 396(PH.05) |
| COM4 | 468(PX.06) |

Contact Window and File Link

- EIoT AE: Jackhsuan.liao Ext. 9319
- E-mail: Jackhsuan.liao@advantech.com.tw

