



ARK-3530 RAID Setting

1. BIOS > chipset >PCH-IO Configuration > SATA and RST Configuration > SATA

Mode Selection > **Intel RST Premium**




2. Save Changes & Reset




3. Reboot and into BIOS

4. Advanced > **Intel® Rapid Storage Technology**




5. select "Create RAID Volume"




6. a. check RAID Level


- b. select disk, choose X



7. "Create Volume"



8. Done



9. Reboot and install OS.