Version:1.0


Advantech AE Technical Share Document

Date	2023 / 11 / 21	**Release Note**	□ Internal ■ External
Category	■ FAQ □ SOP	**Related OS**	Windows 10
Abstract	How to Disable Windows Recovery Environment on Windows 10?		
Keyword	Windows 10, Windows Recovery Environment		
Related Product	Windows 10		

■ Problem Description:


If you want to prevent the computer from entering the Windows Recovery Environment (unable to enter the system normally) after a power outage under abnormal or unknown conditions without using the screen, this FAQ will tell you how to do it.


Please note that changes may cause the system to crash, so be sure to make a backup before making any changes.




■ Brief Solution - Step by Step:

1. Execute the command line with administrator privileges.





2. Key in" **bcdedit**" and check your original setting.
   Here you can see the **identifier** is "**current**".




3. Key in:
   bcdedit /set {Your identifier value} bootstatuspolicy ignoreallfailures
   bcdedit /set {Your identifier value} recoveryenabled No
   Your identifier value is according to the value you see in **identifier** column.

```
C:\Windows\system32>bcdedit /set {current} bootstatuspolicy ignoreallfailures
The operation completed successfully.

C:\Windows\system32>bcdedit /set {current} recoveryenabled No
The operation completed successfully.
```

4. Key in" **bcdedit**" and check again your setting.
   Here you could see **the value of recoveryenabled is changed to "no"**, and you get a new parament **"bootstatuspolicy" "IgnoreAllFailures"**.



5. Reboot the computer and check the value again.
6. Shutdown the computer and now you will not see the Windows Recovery Environment anymore.

- **Reference**:
  https://appuals.com/disable-or-enable-recovery-environment/